

WATERSTEP'S POWER SUPPLY INSTRUCTIONS

3/8/17

The power supply is to be used in place of the 12 volt battery for either the M-100 Chlorine Generator or the Bleach Maker.

To use the power supply:

1. Plug the power cord into an electrical outlet. Use the plug adapter only if necessary. The unit will automatically adjust to the line voltage (110v-240v AC).
2. Plug other end of the power cord into the power supply.
3. Instead of using a battery as described in the instructions of the M-100 or the Bleach Maker, clip the leads to connector box. Clip the red lead to the bolt on the side of the connector box with the red washer and the black lead on the side with the black washer.

Safety precautions:

- The power supply is ON all the time that it is plugged in.
- When not in use, store the power supply where it will stay dry.
- The power supply is to be used with either M-100 Chlorine Generator or the Bleach Maker, but not both at the same time.
- Do not use the power supply to charge a battery or start a vehicle.
- Do not allow children around the power supply.
- Do not operate the power supply in the rain. If the power supply gets wet immediately unplug it and dry it off.
- The power supply has a self protecting internal switch. If it does not appear to be working, unhook the Bleach Maker or the M-100 Chlorine Generator, check the connections and try again..
- Keep all metal objects (tools, jewelry, etc.) away from the power supply and do not use the power supply on a metal table.



